


CLEANING AND LUBRICATION



IMPORTANT

- ONLY WASH THE LIFT WITH THE PLATFORM IN THE RAISED POSITION
- DO NOT FORCE THE PRESSURE WATER JET THROUGH THE COLUMN SLOTS
- IF LUBRICANT IS WASHED AWAY THE LIFT WILL REQUIRE ADDITIONAL RELUBRICATION, OUTSIDE NORMAL SERVICE INTERVALS
- FAILURE TO DO SO, WILL CAUSE JUDDERING AND SLOW OPERATION OF THE LIFT
- IT CAN ALSO CAUSE THE LIFT TO JAM WHEN LOWERING, CAUSING BREAKDOWN AND DOWNTIME